

T12

12-Channel Radio Controller

User Manual

V1.0

2019.05



FOXTECH

Contents

Overview	3
Product Characteristics	3
Main Use and Application Fields	3
Specification	4
Diagram	5
Using Environmental Conditions	6
Working Conditions	6
Security	6
Operation	7
Preparation and Checking Before Use	7
Connect to cellphone APP	11
Receiver / Camera / FC Connection and Setting	12
Connect to Cellphone to Display the Video	13
How to Upgrade the Firmware of T12	14
How to Switch Between Left and Right Hand	15

Overview

Product Characteristics

1. Dual-antenna dual-module redundancy design, combined with algorithm control, greatly increases the signal communication capability. FHSS technology, omni gain antenna, complete operation and configuration of aircraft and camera within communication distance.
2. Reserved TX, RX, return flight data to the ground remote control. Maximize the use of 2.4G wireless Bandwidth, which solves the shortcomings of instability and non-interference in the 433 and 915 bands.
3. Internal integrated digital radio.
4. Use the mobile APP assistant software to set the parameters anytime, anywhere.
5. Bluetooth, USB two connection methods, support for S.BUS, PPM, PWM, I2C and serial port ,support for device expansion.
6. Support mobile phone APP assistant software. Connect your phone app via Bluetooth or USB OTG, fast switch hand type, adjust channel forward and reverse, rudder amount, channel binding, runaway protection value, SBUS, PPM output and data transmission baud rate. Provide one-key parameter adjustment function, you can call it at any time after saving the parameter.
7. Ground station APP has better interactive interface, larger map vision, can control the aircraft to achieve intelligent waypoint planning, automatic execution of tasks, one-key back to home.
8. Built-in 4000MAH lithium-ion battery for more than 24 hours. 100MW ultra low power, And support to charge your phone.
9. Integrated data, video and rc three-in-one link. Ultra-small size, with aluminum alloy embedded folding bracket, sturdy and stable, the jaws rotate 360 degrees, and the two holders can be adjusted 180 degrees.
10. equipped with a mini camera.

Main Use and Application Fields

It is used to remote drones like plant protection drone, for video image transmission, data transmission and radio control.

Specification

Specification:

Weight	490g(controller), 26g(receiver), 15.6g(camera)
Channel	12
Working Voltage	3.7V
Working Current	170mA
Battery Capacity	4000mAh
Endurance	25hours
Frequency	2.400GHz-2.4833GHz
Communication Technology	FHSS
Transmission Distance	10km
Signal Output	SBUS, PWM, I2C

Mini Camera:

Resolution	720P@30
Size	30.2x29.8x26.8mm
Weight	15.6g
Voltage	5V
Current	180mA
Working Temperature	-10°C to +40°C

Diagram



Using Environmental Conditions

1. Environment temperature: $-10^{\circ}\text{C} \sim +55^{\circ}\text{C}$.
2. Storage temperature: $-25^{\circ}\text{C} \sim +70^{\circ}\text{C}$.
3. Relative humidity: no more than 85%.
4. Atmospheric pressure: 86 kPa to 106 kPa.
5. The use of the site is not allowed to explode dangerous media, the surrounding media should not contain corrosive metals and insulating gas and conductive media, not allowed to be filled with water vapor and serious mold.
6. The place of use should have facilities to protect against rain, snow, wind, sand and ash.

Working Conditions

Power supply method and notes.

The T12 series ground unit has built-in integrated rechargeable lithium battery, which is compatible with the market standard micro USB interface 5v/1.5A power adapter (such as mobile phone, camera and other digital products USB charger) for charging.

If you encounter smoke, odor, or liquid leakage when charging on the ground unit, do not continue to charge the ground unit. Please transfer it to our company for repair.



Do not charge the product in the baby's touch area to avoid the risk of electric shock.
Do not charge this product in an environment exceeding 60°C .

Security



Beginners should pay special attention to the following safety issues!

It is forbidden to fly when the body condition is not good, such as fatigue or drunkenness!

It is forbidden to fly in bad weather such as rain or strong wind!

It is forbidden to fly near high-voltage lines, communication base stations, or active places!

It is forbidden to fly at airports and other places where it is forbidden to fly!

It is forbidden to control the flight model in places where people are concentrated, in parking areas, or in other areas where property damage or personal injury may occur.

Before the flight, check the equipment of the aircraft and check whether the transmit and receive system and the aircraft are normal.

After the flight, turn off the power of the receiver and then turn off the power of the transmitter to prevent the engine or motor from rotating and causing damage caused by the runaway protection function!

Please use a guaranteed professional charger to charge the battery.

This product antenna is a fragile component, please pay attention to avoid excessive damage.


Operation

Preparation and Checking Before Use

1. Always check that the remote control is fully charged before use.
2. Please check if the antenna is placed as required before use.
3. For the first time, please ensure that the firmware has been upgraded to the latest version.
4. Users should ensure that they are not operating under the influence of drunkenness or drugs.


Proper Operation

Expand and vertically upward.




Faulty Operation

Antennas can not cross.




Cannot be parallel to the remote controller.




Uav Operation Diagram

Proper Operation

Away from the center plate,vertically upward, no shielding.




Fixed under the arms.




Faulty Operation


Can not place in the center of the plate.



Antenna can not be close to the CF and metal.



Antennas can not cross, and can not be placed in the middle of the tank.



Connect to cellphone APP

1. After installation, confirm that the receiver and the flight controller are correctly installed and ensure that the receiver is working properly.
2. APP currently only supports Android.
3. Install the APP on your mobile phone.
4. Power on the remote controller (short press + long press), enter the phone system settings interface to open Bluetooth, search for Bluetooth: T12-XXX. The pairing code is 1234.
5. Open the device assistant APP, as shown below(Figure 1).

Adjust parameter of remote controller---- used to adjust the channel forward and reverse, rudder amount, channel binding, runaway protection value.

Hand Switching—Used to correct the maximum and minimum offsets of the median point.

Usually do not need to move, otherwise it may cause abnormal rudder.

Other options - used to select the receiver SBUS, PPM output, and digital baud rate.

Device upgrade----for updating firmware online.

Connection method, please use Bluetooth for remote control, USB for receiver.(Figure 1)




Figure 1

6. Remote control parameter adjustment, enter the controller adjustment interface. The app will read the current values of the remote controller and receiver (Figure 2).

For Example:

Channel 1: Binding key is X2, no reverse, failsafe 1500, minimum rudder is 1000, maximum rudder is 2000

Channel 2: Binding key is Y2, no reverse, failsafe 1500, minimum rudder is 1000, maximum rudder is 2000

Channel 3: Binding key is Y1, no reverse, failsafe 900, minimum rudder is 1000, maximum rudder is 2000

Channel 4: Binding key is X1, no reverse, failsafe 1500, minimum rudder is 1000, maximum rudder is 2000



1. failsafe fill in "0"(default 1500)
2. Click on the upper right corner to write, otherwise you will not be able to record the transmitter and receiver.



Figure 2

7. Parameter saving, parameter loading (Figure 3, 4, 5).

In order to change the drone model, or for batch configuration. We can save the parameters inside the APP. Each time you load a parameter and write to the remote controller, you can quickly configure it.

As shown in the figure: adjust the parameters, click on the "three points", and will popup menu in the upper right corner and select Save.

Customize your own name and save it. Load the parameters in the same way.



The parameters are only saved in the APP. If you need to write to the remote controller, please click "Write". you will hear a "Di" when the remote communication is succeed.



Figure 3



Figure 4



Figure 5

Receiver / Camera / FC Connection and Setting

1. Receiver



Figure 6

2. Short-circuit MODE KEY and GND to enter the frequency pairing mode, the green light flashes quickly turn on the remote controller and will complete the frequency pairing, after the frequency pairing the green light is always on.

3. The digital transmission pin is as shown in the figure. Please insert the corresponding cable to flight control. The receiver TX corresponds to the flight control RX.

4. USB upgrade port is used to upgrade the receiver firmware, short-circuit the MODE KEY and GND buttons, insert the 4 button wiring of the USB upgrade into the computer, the receiver light will automatically turn red and flash slowly into the download mode.

5. Fault light:

The red light flashes quickly---the receiver does not pass the self-test, and it needs to be re-tested, if fails, need to return to the factory.

The red light and green light is turned on and flashes on alternately, which belongs to the self-test.

The self-test passed, the green light is not on---the remote controller is not on, and not do frequency pairing.

There is no reaction when the power is turned on---Check if the power supply is 5v, and whether the positive and negative poles are reversed. If all is normal, please return to factory.

Connect to Cellphone to Display the Video

1. Properly solder the receiver to the camera and power up the unit.
2. Install the FUAV APP.
3. Connect the remote control to the phone with USB as shown in Figure 7.
4. Click OK in the pop-up USB window to display the image. (Figure 8)



Figure 7



Figure 8

How to Upgrade the Firmware of T12

1. Android upgrade

Download the device assistant and connect to the remote controller with Bluetooth. Select Bluetooth, refer to the first part.

Turn off the remote control, press and hold the "A button" then turn it on, the remote control A light flashes slowly into the download mode.

Open the device assistant, click "Check for updates", and if you have new firmware, click Upgrade Now.



Click "check the update", it will prompt whether upgrade the receiver etc. Please observe carefully, because that most of the time you do not need to upgrade the receiver.

2. Computer upgrade, tool download site: <https://www.foxtechfpv.com/t12-12-channel-radio-controller.html>

3. Remote controller upgrade.

-The remote control is connected to the computer with a dual male data cable. Turn off the remote control, press and hold the "A button" and then turn it on, remote control A light flashes slowly and enter the download mode.

-Double-click [Firmware Upgrade Program] (Figure 9)

-Select the corresponding bin file and click Upgrade Now. When the progress is 100%, the upgrade is completed. Please turn off the remote controller.

4. Receiver upgrade:



-Receiver upgrade (if needed), use USB cable, press the S1 button to insert the useb cable to the computer, the receiver light will automatically turn red to enter the download mode.

-Select the corresponding bin file and click Upgrade Now. When the progress is 100%, the upgrade is completed. Please unplug the receiver.



How to Switch Between Left and Right Hand

There are 4 hand types in the device assistant.



This content is subject to change.

Download the latest version from

<https://www.foxtechfpv.com/t12-12-channel-radio-controller.html>

For everyday updates, please follow

Foxtech Facebook page: <https://www.facebook.com/foxtechhobby>

YouTube Channel: https://www.youtube.com/user/foxtechonline/featured?view_as=subscriber